

# Millennium APM Oil Mist Detector Air Particle Monitor



## Important Instructions

Rosemount designs, manufactures and tests products to function within specific conditions. Because these products are sophisticated technical instruments, it is important that the owner and operation personnel must strictly adhere both to the information printed on the product nameplate and to all instructions provided in this manual prior to installation, operation, and maintenance.

### **WARNING!**

**Installing, operating, or maintaining this product improperly could lead to serious injury or death from explosion or exposure to dangerous substances. Comply with all information on the product, in this manual, and in any local and national codes that apply to the product. Do not allow untrained personnel to work with this product. Use Net Safety parts and work procedures specified in this manual.**

---

No part of the hardware, software, or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Rosemount.

While great efforts have been made to ensure the accuracy and clarity of this document, Rosemount assumes no liability resulting from any omissions in this document or from misuse of the information obtained herein. The information in this document has been carefully checked and is believed to be entirely reliable with all of the necessary information included. Rosemount reserves the right to make changes to any products described herein to improve reliability, function, or design and reserves the right to revise this document and make changes from time to time in content hereof with no obligation to notify any persons of revisions or changes. Rosemount does not assume any liability arising out of the application or any use of any product or circuit described herein; neither does it convey license under its patent rights or the rights of others.

### **WARNING!**

**This manual should be read carefully by all individuals who have or will have responsibility for using, maintaining, or servicing the product.**

**The Detector is not field repairable due to the meticulous alignment and calibration of the sensors and the respective circuits. Do not attempt to modify or repair the internal circuits or change their settings, as this will impair the system's performance and void the Rosemount product warranty.**

---

## Warranty

- Limited Warranty** . Subject to the limitations contained in Section 2 (Limitation of Remedy and Liability) herein, Seller warrants that (a) the licensed firmware embodied in the Goods will execute the programming instructions provided by Seller; (b) that the Goods manufactured by Seller will be free from defects in materials or workmanship under normal use and care; and (c) Services will be performed by trained personnel using proper equipment and instrumentation for the particular Service provided. The foregoing warranties will apply until the expiration of the applicable warranty period. Sensors and detectors are warranted against defective parts and workmanship for 24 months from the date of purchase and other electronic assemblies for 36 months from the date of purchase. Products purchased by Seller from a third party for resale to Buyer (Resale Products) shall carry only the warranty extended by the original manufacturer. Buyer agrees that Seller has no liability for Resale Products beyond making a reasonable commercial effort to arrange for procurement and shipping of the Resale Products. If Buyer discovers any warranty defects and notifies Seller thereof in writing during the applicable warranty period, Seller shall, at its option, (i) correct any errors that are found by Seller in the firmware or Services; (ii) repair or replace FOB point of manufacture that portion of the Goods found by Seller to be defective; or (iii) refund the purchase price of the defective portion of the Goods/Services. All replacements or repairs necessitated by inadequate maintenance; normal wear and usage; unsuitable power sources or environmental conditions; accident; misuse; improper installation; modification; repair; use of unauthorized replacement parts; storage or handling; or any other cause not the fault of Seller, are not covered by this limited warranty and shall be replaced or repaired at Buyer's sole expense and Seller shall not be obligated to pay any costs or charges incurred by Buyer or any other party except as may be agreed upon in writing in advance by Seller. All costs of dismantling, reinstallation, freight, and the time and expenses of Seller's personnel and representatives for site travel and diagnosis under this limited warranty clause shall be borne by Buyer unless accepted in writing by Seller. Goods repaired and parts replaced by Seller during the warranty period shall be in warranty for the remainder of the original warranty period or 90 days, whichever is longer. This limited warranty is the only warranty made by Seller and can be amended only in a writing signed by an authorized representative of Seller. The limited warranty herein ceases to be effective if Buyer fails to operate and use the Goods sold hereunder in a safe and reasonable manner and in accordance with any written instructions from the manufacturers. THE WARRANTIES AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE. THERE ARE NO REPRESENTATIONS OR WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, AS TO MERCHANTABILITY, FITNESS FOR PARTICULAR PURPOSE OR ANY OTHER MATTER WITH RESPECT TO ANY OF THE GOODS OR SERVICES.
- Limitation of Remedy and Liability** SELLER SHALL NOT BE LIABLE FOR DAMAGES CAUSED BY DELAY IN PERFORMANCE. THE REMEDIES OF BUYER SET FORTH IN THE AGREEMENT ARE EXCLUSIVE. IN NO EVENT, REGARDLESS OF THE FORM OF THE CLAIM OR CAUSE OF ACTION (WHETHER BASED IN CONTRACT, INFRINGEMENT, NEGLIGENCE, STRICT LIABILITY, OTHER TORT, OR OTHERWISE), SHALL SELLER'S LIABILITY TO BUYER AND/OR BUYER'S CUSTOMERS EXCEED THE PRICE TO BUYER OF THE SPECIFIC GOODS MANUFACTURED OR SERVICES PROVIDED BY SELLER GIVING RISE TO THE CLAIM OR CAUSE OF ACTION. BUYER AGREES THAT IN NO EVENT SHALL SELLER'S LIABILITY TO BUYER AND/OR BUYER'S CUSTOMERS EXTEND TO INCLUDE INCIDENTAL, CONSEQUENTIAL OR PUNITIVE DAMAGES. THE TERM "CONSEQUENTIAL DAMAGES" SHALL INCLUDE, BUT NOT BE LIMITED TO, LOSS OF ANTICIPATED PROFITS, REVENUE OR USE AND COSTS INCURRED INCLUDING WITHOUT LIMITATION FOR CAPITAL, FUEL AND POWER, AND CLAIMS OF BUYER'S CUSTOMERS.



# Contents

<b>Chapter 1</b>	<b>Introduction .....</b>	<b>1</b>
	1.1 Models covered .....	1
	1.2 Service support .....	1
	1.3 Return of material .....	1
	1.4 Product recycling/disposal .....	2
<b>Chapter 2</b>	<b>Installation .....</b>	<b>3</b>
	2.1 Unpacking and inspection .....	3
	2.2 Locate sensor .....	3
	2.3 Dimensions .....	5
	2.4 Mounting .....	7
	2.4.1 Duct mounting .....	8
	2.5 Wiring .....	9
	2.5.1 Field installation .....	9
	2.5.2 Seals .....	10
	2.5.3 Sensor separation .....	10
	2.5.4 Board assembly .....	11
	2.5.5 Installation to transmitter or junction box .....	11
	2.5.6 Faceplate rotation .....	12
	2.5.7 General requirements .....	13
	2.5.8 Wiring sensor to transmitter .....	14
	2.5.9 Wiring sensor to junction box .....	15
	2.5.10 Wiring transmitter to control system .....	17
	2.5.11 External ground .....	17
	2.6 Current output .....	18
	2.7 Non-isolated and isolated power configurations .....	19
	2.8 Installation checklist .....	20
<b>Chapter 3</b>	<b>Operation .....</b>	<b>21</b>
	3.1 Millennium transmitter .....	21
	3.1.1 Display .....	21
	3.1.2 Status LED .....	21
	3.1.3 On/Off switch .....	22
	3.1.4 Setup button .....	22
	3.1.5 Magnetic Reed switch .....	22
	3.1.6 Current output check .....	22
	3.2 Indications and outputs .....	23
	3.3 Alarms .....	23
	3.3.1 APM fault .....	23
	3.3.2 Clean window/dirty chamber .....	23
	3.3.3 Particulate alarm .....	24
	3.4 Reset .....	24
	3.4.1 Remote reset .....	24
	3.4.2 Manual reset .....	24
	3.5 Normal .....	24
	3.6 Outputs .....	24

	3.6.1	Relays .....	24
	3.6.2	Current .....	25
3.7		APM Sensor .....	25
	3.7.1	Sensor power up .....	25
	3.7.2	Sensor communication .....	25
<b>Chapter 4</b>		<b>Programming .....</b>	<b>27</b>
	4.1	Main menu .....	27
	4.2	Accessing the main menu .....	27
	4.3	Main menu functionality .....	27
	4.3.1	Zero .....	28
	4.3.2	Sensitivity settings .....	29
	4.3.3	Review relay settings .....	30
	4.3.4	Set relay options .....	30
	4.3.5	Select display language .....	33
<b>Chapter 5</b>		<b>Maintenance .....</b>	<b>35</b>
	5.1	Response check .....	35
	5.2	Cleaning .....	35
	5.3	Troubleshooting .....	36
	5.4	Storage .....	36
	5.5	Spare parts and accessories .....	37
<b>Chapter 6</b>		<b>Electrostatic sensitive device .....</b>	<b>39</b>
<b>Chapter 7</b>		<b>Wire resistance table .....</b>	<b>41</b>
<b>Chapter 8</b>		<b>Specifications .....</b>	<b>43</b>
	8.1	Electrical .....	43
	8.1.1	Operating voltage range .....	43
	8.1.2	Power consumption .....	43
	8.1.3	Current output .....	43
	8.2	Environmental .....	43
	8.2.1	Storage temperature .....	43
	8.2.2	Operating temperature .....	43
	8.2.3	Relative humidity .....	43
	8.2.4	Metallurgy .....	44
	8.2.5	Ingress protection .....	44
	8.2.6	Weight .....	44
	8.3	Separation .....	45
	8.4	Warranty .....	45
<b>Chapter 9</b>		<b>Certifications .....</b>	<b>47</b>
	9.1	North American hazardous locations .....	47
	9.1.1	Transmitter .....	47
	9.1.2	APM Sensor .....	47
	9.1.3	Junction box (Model JB-MPD) .....	48
	9.2	ATEX (-X model) .....	48
	9.2.1	Transmitter .....	48
	9.2.2	APM Sensor .....	48
	9.2.3	Junction box (Model JB-MPD) .....	49
	9.3	IECEX (-X model) .....	49
	9.3.1	Transmitter (aluminum) .....	49
	9.3.2	Transmitter (stainless steel) .....	49

9.3.3	APM Sensor .....	49
9.3.4	Junction Box (Model JB-MPD) .....	49
<b>Chapter 10</b>	<b>Ordering information .....</b>	<b>51</b>





# 1 Introduction

## 1.1 Models covered

The Air Particle Monitor (APM) is an infrared optical detector used in hazardous industrial applications to monitor ambient air for the presence of particulate matter from products of combustion such as carbon, air particulate matter, or ash.

The Millennium Transmitter is an environmentally protected electronic package contained within an explosion-proof housing. With its scrolling 8-character display and status LEDs, it provides instructions and status alerts.

The APM Sensor is mounted where airborne particles are anticipated to accumulate while the Millennium Transmitter is located conveniently at eye level.

The product is available in aluminum and stainless steel (SS).

Models available are:

- MLP-AR-APM-OP - APM, 4-20mA analog output with alarm & fault relays, aluminum housing, CSA approved
- MLP-AR-APM-OP-X - APM, 4-20mA analog output with alarm & fault relays, aluminum housing, CSA, ATEX, and IECEx approved
- MLP-AR-APM-OP-SS - APM, 4-20mA analog output with alarm & fault relays, stainless steel housing, CSA approved
- MLP-AR-APM-OP-SS-X - APM, 4-20mA analog output with alarm & fault relays, stainless steel housing, CSA, ATEX, and IECEx approved

## 1.2 Service support

Technical support for this product can be provided by contacting your local Emerson/Net Safety representative or by contacting the Net Safety Technical Support department at: Toll Free + 866 347 3427 or [Safety.CSC@emerson.com](mailto:Safety.CSC@emerson.com).

## 1.3 Return of material

To expedite the repair and return of this product, proper communication between the customer and the factory is important. Before returning a product for repair, call +1 403 219-0688 or e-mail [Safety.CSC@emerson.com](mailto:Safety.CSC@emerson.com) for a Material Return Authorization (MRA) number.

On the return of the equipment, include the following information:

### Procedure

1. MRA number provided to you by Net Safety

2. Company name and contact information
3. Purchase order, from your company, authorizing repairs or request for quote
4. Ship all equipment, prepaid to:  
  
Emerson Automation Solutions  
158 Edinburgh Ave  
Slough, United Kingdom SL 1 4UE
5. Mark all packages with as Return for Repair and include MRA number  
  
Pack items to protect them from damage and use anti-static bags or aluminum-backed cardboard as protection from electrostatic damage.

---

**Important**

All equipment must be shipped prepaid. Collect shipments will not be accepted.

---

## 1.4 Product recycling/disposal


Recycling of equipment and packaging should be taken into consideration and disposed of in accordance with local and national legislations/regulations.

## 2 Installation

### 2.1 Unpacking and inspection

Carefully remove all of the components from the packaging and verify them against the enclosed packing list. Inspect all components for any obvious damage such as broken or loose parts. If you find any components missing or damaged, notify your local Net Safety representative or the factory immediately. [Figure 2-1](#) outlines the components supplied with the APM.

**Figure 2-1: APM components**




### 2.2 Locate sensor

Prior to the installation process, a location plan for placing the APM sensor and transmitter should be developed. Proper location of the APM sensor is essential for providing maximum protection. The most effective placement and number of detectors varies depending upon conditions. The following points should be considered when planning the installation.

- Carefully locate the APM sensor in an area where particulate may potentially accumulate.
- The APM sensor should be located where it is safe from potential sources of contamination such as oil film, dirt, etc.

- Locate the transmitter where it will be accessible and visible.
- Mount the APM sensor so air currents allow particulate to flow into the optical path of the sensor.
- If the particulate is expected to be moving horizontally due to air currents, orient the sensor for maximum detection as shown in [Figure 2-1](#).
- Exposure to excessive heat or vibration can cause premature failure of electronic devices and should be avoided whenever possible.
- Seek advice from experts and refer to various regulatory publications that discuss general guidelines for your industry.
- The APM works off of the principle of infrared energy being reflected off of particulate matter passing through the optical path of the APM. Therefore, give careful consideration when installing the APM to ensure that external infrared light does not reach the sensing element.


[Figure 2-2](#) illustrates a typical installation of an APM sensor and transmitter. The APM sensor is mounted separately from the transmitter using the supplied junction box. The transmitter is located at eye level, while the sensor is located where particles are most likely to accumulate. The conduit then connects the two devices.

**Figure 2-2: Typical installation**


## 2.3 Dimensions

The following figures outline the dimensions of the APM connected directly to the Millennium transmitter ([Figure 2-3](#)) or when connected directly to the multi-purpose junction box ([Figure 2-4](#)). There are three (3) 3/4" NPT conduit entries available on the Millennium transmitter. Adapters for M20 and 1/2" NPT threads are also available as spare parts.

**Figure 2-3: Transmitter Dimensions**



**Figure 2-4: Junction Box & Sensor Dimensions**



## 2.4 Mounting

The sensor must be mounted directly to either a transmitter or to a separate junction box through a 3/4" NPT conduit entry. Both the transmitter and junction boxes have mounting holes to allow mounting to a wall or pole as desired. Mounting kit hardware is required when mounting the transmitter or junction box to a pole. Contact your local Net Safety representative for detailed information on the pole mounting kits.

The transmitter should be mounted at eye-level and be easily accessible for monitoring and maintenance purposes. The sensor should be placed where particles are likely to accumulate and across the direction of the airflow to allow the particulates to pass through the optical path. To prevent water damage, seal conduit at all points of entry to the transmitter or junction box.

It is recommended that the APM sensor be mounted such that the air flow will pass through the optical path of the sensor as shown in [Figure 2-5](#).


---

### Note

The APM works off of the principle of infrared energy being reflected off of particulate matter passing through the optical path of the APM. Therefore, give careful consideration when installing the APM to ensure that external infrared light does not reach the sensing element.

---

The APM may be affected by sudden bursts of infrared light; therefore, it is recommended that a time delay (between two (2) to five (5) seconds) be put into the monitoring system to prevent nuisance alarms.

**Figure 2-5: APM Mounting Locations**


### 2.4.1 Duct mounting

Although the Net Safety Monitoring Air Particle Monitor has been proven to detect particulate matter travelling at speeds of up to 20 meters per second (65.62 feet per second) the detector is virtually unaffected by the velocity of particulate and air that it is exposed to. Based on the application and the speed of the particulate matter, you can perform a zero and adjust the sensitivity settings to suit the application.

Net Safety Monitoring recommends the APM be used with the UDM-001 or UDM-002 sample draw system to acquire a cross-sectional sample of air and particulate moving through ducts. The sample is drawn through perforations along the inlet pipe into a chamber where the APM is mounted. Particulate matter from the outlet pipe is then returned to the duct. Refer to [Figure 2-6](#) and the UDM-001/UDM-002 reference manual (MAN-0116) for more information.



Figure 2-6: Air Flow Drawing



## 2.5 Wiring

### 2.5.1 Field installation

#### **⚠ WARNING!**

Failure to follow these installation guidelines could result in death or serious injury. Ensure that only qualified personnel perform the installation.

Electrical shock could cause death or serious injury. Use extreme caution when making contact with the leads and terminals.

Do not open the transmitter, sensor, or junction box enclosure when in a classified area or when an explosive atmosphere may be present unless the power to the transmitter has been removed.

Avoid touching electronic components as they are susceptible to electrostatic discharge (ESD). Refer to [Chapter 6](#) for more information.

Avoid contact with the non-metallic enclosure label as contact may create an electrostatic charging hazard.

**NOTICE**

**Wiring codes and regulations may vary. ATEX requires that supply connections wiring must be rated at least 41 °F (5 °C) above the maximum ambient temperature of 185 °F (85 °C). Wiring must comply with all applicable regulations relating to the installation of electrical equipment in a hazardous area and is the responsibility of the installer. If in doubt, consult a qualified official before wiring the system.**

When separating the sensor from the transmitter, the use of shielded cable is highly recommended to protect against interference caused by extraneous electrical or electromagnetic noise to meet mandatory CE mark electromagnetic compatibility (EMC) requirements. In applications where the wiring is installed in conduit, the conduit must not be used for wiring to other equipment.

## 2.5.2 Seals

The use of seals is recommended to further protect the system against any unwanted water ingress, and equipment should be installed according to applicable local electrical codes. Seals are especially recommended for installations that use high-pressure or steam cleaning devices in proximity to the transmitter and/or sensor.

- Water-proof and explosion-proof conduit seals are recommended to prevent water accumulation within the enclosure.
- Seals should be located as close to the device as possible and not more than 18 inches (46 cm) away.
- Explosion-proof installations may require an additional seal where conduit enters a non-hazardous area. Ensure conformity with local wiring codes.
- When pouring a seal, use a fiber dam to assure proper formation of the seal. Seals should never be poured at temperatures below freezing.
- The jacket and shielding of the cable should be stripped back to permit the seal to form around the individual wires. This will prevent air, particles, and water leakage through the inside of the shield and into the enclosure.
- It is recommended that explosion-proof drains and conduit breathers be used. In some applications, alternate changes in temperature and barometric pressure can cause *breathing* which allows moist air to enter and circulate inside the conduit. Joints in the conduit system are seldom tight enough to prevent this *breathing*.

## 2.5.3 Sensor separation

Since the APM Sensor must be located where it will pick up particulate in an air flow, and the transmitter where it can be easily reached, it is often necessary to separate the transmitter and sensor. This is done with the aid of the included sensor separation kit (SEP). This kit is composed of a junction box and terminal strip. Refer to the Net Safety Multi-purpose Junction Box manual (MAN-0081) for terminal designation.

The maximum separation distance between the sensor and the transmitter is limited by the resistance of the connecting wiring, which is a function of the gauge of wire being used. Net Safety recommends that sensor separation must not exceed 2000 feet (610 meters) while using 16 AWG (1.31 mm<sup>2</sup>) wire. Refer to [Chapter 7](#) for wire gauges and resistance values.


#### Note

When the sensor is separated from the transmitter, always ensure that the transmitter is supplying the required voltage to the sensor terminals inside the junction box. If the 4-20 mA signal is not used, connect a jumper between the 4-20 terminal and the COM terminal on the transmitter terminal board.

## 2.5.4 Board assembly

There are three different fixed boards and a relay board which make up the PCB assembly. Simply loosen the three locking standoffs, remove one board, insert the other board and tighten screws. The boards are susceptible to ESD. Refer to [Chapter 6](#) for further information on proper handling of this equipment.

**Figure 2-7: Millennium transmitter module boards**



## 2.5.5 Installation to transmitter or junction box

The APM sensor is supplied with a 3/4" NPT male conduit connection and is intended to be mounted directly to an available 3/4" NPT conduit entry on the Millennium transmitter or remotely using the supplied junction box.

The sensor should be tightly threaded to the transmitter or junction box. A minimum of seven (7) threads need to be engaged to ensure proper water ingress protection and the explosion proof rating of the devices. Proper care needs to be taken to ensure that no damage is caused to the wires on the APM sensor and circuit board inside the transmitter and junction box.


The use of conductive grease is recommended on the threads.

The sensor can be mounted in a number of configurations to ensure that air particulate will pass through the optical path of the sensor. It is recommended that the APM be mounted horizontally to ensure that build-up of dirt, dust, and debris will not affect the operation of the sensor.

## 2.5.6 Faceplate rotation

In some applications, it is necessary for the Millennium transmitter to be mounted in a non-standard orientation. To accommodate such installations and ensure that the display will appear at the correct angle for viewing, the PCB assembly can be rotated inside the transmitter's housing. [Figure 2-8](#) outlines non-standard orientations of the Millennium transmitter.

**Figure 2-8: Non-standard Orientation**



### **⚠ WARNING!**

**Do not open the transmitter, sensor, or junction box enclosure when in a classified area or when an explosive atmosphere may be present unless the power to the transmitter has been removed.**


The following section describes the steps required to rotate the Millennium transmitter faceplate. Refer to [Figure 2-9](#) for the components in the transmitter housing. The boards may be susceptible to ESD. Refer to [Chapter 6](#) for further information on proper handling of this equipment.

### **Procedure**

1. Remove the transmitter housing cover.
2. Turn the power to the transmitter off.
3. Unscrew both the knobs marked *Pull Here*.
4. Lift the transmitter faceplate from the housing and allow to the faceplate to hang from the ribbon cable.
5. Unscrew the two metal standoffs.
6. Carefully remove the PCB assembly from the housing.
7. The rotator plate is secured to the bottom of the housing and is accessible after the PCB assembly has been removed.

8. Rotate the PCB assembly to the desired position and line up the standoffs with the mounting holes.
9. Insert standoffs in the appropriate horizontal or vertical mounting holes.
10. Tighten standoffs to secure the PCB assembly.
11. Replace faceplate and tighten *Pull Here* knobs.
12. Return power to the detector and replace the housing cover.

**Figure 2-9: PCB Assembly Rotated**



## 2.5.7 General requirements


### **⚠ WARNING!**

Do not open the transmitter, sensor, or junction box enclosure when in a classified area or when an explosive atmosphere may be present unless the power to the transmitter has been removed.

When connecting cable wires, use a small screwdriver to gently press down and hold the spring connector open. Insert the appropriate wire into the open connector hole, releasing the screwdriver to secure the wire as shown in [Figure 2-10](#).

The connector will accommodate wire sizes between 14 and 20 AWG.

**Figure 2-10: Terminal connection**




## 2.5.8 Wiring sensor to transmitter

Connect the sensor wires to the Millennium transmitter as shown in [Figure 2-11](#). [Table 2-1](#) outlines the wire colors and their purpose.

**Table 2-1: Sensor wire colors and terminal definition**


Wire color	White	Blue	Red	Black	Shield
Marking	+24 Vdc	Sig A	Sig B	COM(-)	Shld
Function	10.5-32 Vdc connection	Communication signal A	Communication signal B	Common / supply ground	Earth ground

**Figure 2-11: Millennium sensor wiring**

## 2.5.9 Wiring sensor to junction box

Sensor wiring side refers to wiring between sensor and junction box. Transmitter wiring side refers to wiring between Millennium (MLP) Transmitter and junction box.

**Figure 2-12: Junction Box Wiring (Model JB-MPD)**



**Note:** Shield should be terminated at Earth Ground at Panel/PLC/DCS/RTU

**Table 2-2: Sensor Wiring**

Terminal	Color	Function
1 (GND)	Green	Earth ground
2	White	Vdc (+)
3	Black	COM (-)
4	Blue	A (communication)
5	Red	B (communication)
6	n/a	Not used
7	n/a	Not used



**Table 2-3: Transmitter Wiring**

Terminal	Function/markings
1 (GND)	Earth ground
2	Vdc (+)
3	COM (-)
4	Sig A
5	Sig B
6	Not used
7	Not used

## 2.5.10 Wiring transmitter to control system

Connect the Millennium transmitter to the control system as shown in [Figure 2-11](#). [Table 2-4](#) outlines the terminal marking and their purpose.


**Table 2-4: Transmitter connections**

Marking	RST	+24V	COM	4-20	+VISO
Function	Remote reset	10.5-32 Vdc Connection	Common / supply ground	Current loop output (mA)	+24 Vdc isolated 4-20 power

## 2.5.11 External ground

In order to ensure proper operation of the sensor, an external earth ground is recommended. Net Safety recommends that the external ground be connected to the grounding point on the enclosure. Refer to [Figure 2-13](#) for grounding connection location.

**Figure 2-13: External grounding point**



## 2.6 Current output

To set the current output, simply move the jumper located on the Terminal Board near the power terminals, to the isolated or non-isolated current position. Refer to [Figure 2-14](#).


---

### Note

Unless otherwise specified, all models ship with this jumper in the non-isolated current position (Pin 2 and Pin 3 jumped). Refer to [Figure 2-14](#).

---

**Figure 2-14: Jumper locations**




## 2.7 Non-isolated and isolated power configurations

For current source using Non-Isolated configuration, the jumper must remain in the default position (Pin 2 and Pin 3 jumped). The jumper is placed over Pin 1 and Pin 2 for current sink using Non-Isolated configuration.

For Isolated configuration using a separate power supply to isolate the current loop, the jumper must be placed over Pin 1 and Pin 2 for source and sink. Refer to [Figure 2-15](#).

Note the Jumper position for each configuration.

Figure 2-15: Current source and sink drawing



## 2.8 Installation checklist

Review the following checklist prior to turning the power on to the transmitter after installation has been completed:

- Ensure that the transmitter and sensor are properly and firmly mounted.
- Ensure that stopping plugs are securely tightened on any unused conduit entries.
- Ensure that the transmitter and sensor are not obstructed, such that they are accessible and the particulate matter is not inhibited from reaching the sensors optical path.
- Ensure adherence to applicable local guidelines and requirements on wiring and sealing of equipment in hazardous and non-hazardous areas.
- Ensure that proper shielding and grounding practices are adhered to and local codes are being followed.
- Check system operational voltage and conditions and ensure that they are within the applicable specifications of the transmitter and sensor.
- Verify wiring at all termination and junction points (transmitter, junction box, and power supply).
- Ensure that the transmitter housing cover and sensor cap are tightly secured.

## 3 Operation


### 3.1 Millennium transmitter

#### **⚠ WARNING!**

Do not open the transmitter, sensor, or junction box enclosure when in a classified area or when an explosive atmosphere may be present unless the power to the transmitter has been removed.

Figure 3-1 outlines the components on the Millennium transmitter and the subsequent paragraphs provide explanations for each component.

**Figure 3-1: Millennium transmitter layout**



#### 3.1.1 Display

A scrolling 8 character display is provided to show various status messages and prompts. Refer to [Table 3-1](#) for the various display messages.

#### 3.1.2 Status LED

The Status LED is used to provide visual indication as to the status of the transmitter and sensor. Refer to [Section 3.2](#) Indications and outputs for specific status conditions of the LED.

### 3.1.3 On/Off switch

The On/Off switch is used to turn power on and off to the transmitter and sensor. Since the transmitter's housing must be opened to access the On/Off switch, the area where the transmitter is located must be de-classified prior to using.

### 3.1.4 Setup button

The Setup button provides access to the Millennium transmitter's main menu, which in turn allows options to be reviewed and set. The Setup button is also used to zero the sensor. Since the transmitter's housing must be opened to access the button the area must be de-classified before using. Refer to [Chapter 4](#) for instructions on programming the Millennium transmitter.

### 3.1.5 Magnetic Reed switch

The magnetic Reed switch is provided to avoid opening the housing in an environment where gas may be present. The magnetic Reed switch functions in the same manner as the setup button but in a non-intrusive manner. The magnet comes permanently attached to the side of the transmitter.

### 3.1.6 Current output check

Current output check test jacks are provided to facilitate current loop measurements without breaking external current loop. To take current loop measurements, ensure wiring is correct and current loop is closed, and then follow steps below

- Set meter on mA scale and insert meter leads into test jacks.
- Put external devices in bypass, if necessary, to avoid unwanted alarm response.
- Perform simulated tests to check output.
- Remove meter leads from test jacks and return external devices to normal.

## 3.2 Indications and outputs

**Table 3-1: Transmitter indications**

State	Current Output	Status LED	Display
Main menu entered	3.0 mA	Solid green	Main menu items
Normal operation	4.0 mA	Green blip	Clear
Startup delay	3.0 mA	Slow red flash	Start delay
Dirty optics	3.3 mA	Fast red flash	Dirty chamber
Particulate present	20 mA	Red blip	Alarm
Fault Condition	2.5 mA	Fast red flash	Fault
Updating APM Sensor	3.0 mA	Slow red flash	Busy

## 3.3 Alarms

### 3.3.1 APM fault

To ensure proper response, the Millennium features self-testing circuitry that continuously checks for problems. When power is applied, the system automatically begins a test to ensure proper functionality.

During normal operation, the transmitter continuously monitors the signal from the internal APM source. If the transmitter determines that the APM program is not running correctly and reset of the APM sensor will occur.

### 3.3.2 Clean window/dirty chamber

Over an extended period, oily film or particulate build-up on the sensor window may obscure the infrared (IR) detector. When dirty, the clean window alarm will trip, the message *Dirty Chamber* displays, the Status LED will flash fast red and the current output will be 3.3 mA. Refer to [Section 4.3.2](#) to define the clean window sensitivity and [Section 5.2](#) on cleaning the APM window.

### 3.3.3 Particulate alarm

When particulate is present in the APM's chamber, the message *Alarm* displays, the Status LED blips red, and the current output is 20.0 mA. If the relay has been set to non-latching, the unit will reset itself; if set to latching, a manual or remote reset is required to clear the alarm condition. Refer to [Section 3.4](#).

---

**Note**

The APM may be affected by sudden bursts of infrared light; therefore, it is recommended that a time delay (between two (2) to five (5) seconds) be put into the monitoring system to prevent nuisance alarms.

---

## 3.4 Reset

### 3.4.1 Remote reset

The Millennium is capable of remote reset. A normally open push-button switch must be connected between the RST terminal and the COM terminal on the terminal board. If relay is set to Latching, a remote reset is possible.

### 3.4.2 Manual reset

If a relay is set to Latching, a manual reset is required to clear the alarm condition. Simply place and hold the magnet against the Reed switch or press and hold the setup button for 3-5 seconds. The unit will return to the normal operation.

## 3.5 Normal

With no particulate present and no fault detected, the display reads `Clear`, Status LED blips/blinks green, and the current output is 4.0 mA.

## 3.6 Outputs

### 3.6.1 Relays

All relay outputs have FORM-C SPDT contacts rated 5 amperes at 30 Vdc/250 Vac. Relays are dry contacts.



## 3.6.2 Current

A 4-20 mA dc current output is used to transmit the alarm status and fault conditions to other devices. This output can be wired for isolated or non-isolated operation. A 4.0 mA output indicates normal operation; a 20.0 mA output indicates that the alarm threshold has been exceeded. Current output of 2.5 mA indicates the presence of a system fault. Current output of 3.3 mA indicates a build-up of particulate in the sensor's chamber or dirty window. Refer to [Section 3.2](#) for additional indications and outputs.

## 3.7 APM Sensor

### 3.7.1 Sensor power up

When power is applied to the sensor by the transmitter, a warm-up routine will begin and the sensor will be automatically tested to ensure proper functioning. The warm-up time for the APM sensor is typically one hundred and fifty (150) seconds. After the warm-up cycle has completed the display will read *Clear*.

As part of the self-diagnostic routine of the Millennium transmitter, the analog output will output 20mA on initial power up for a period not greater than 450 milliseconds. If routine power loss is expected on the system, appropriate actions should be taken to limit false alarm conditions due to this diagnostic routine.

### 3.7.2 Sensor communication

The APM sensor uses a proprietary protocol to communicate with the Millennium transmitter. The APM sensor should never be connected to any device other than a Millennium transmitter. If any problems develop, please refer to the troubleshooting section of this manual.



# 4 Programming

## 4.1 Main menu

The main menu provides access to various functional settings and viewing of current settings. The following options/settings are available in the main menu.

- Set Zero
- Sensitivity Settings
- Review Relay Settings
- Set Relay Options
- Select Display Language

## 4.2 Accessing the main menu

There are two ways to access the main menu, either by using the setup button on the faceplate of the transmitter or utilizing the magnetic Reed switch.

Press and hold the Setup button to access the main menu.

Place and hold the magnet to the transmitter's housing (10 o'clock position as shown in [Figure 3-1](#)) to access the main menu.

## 4.3 Main menu functionality

Ensure that the transmitter has been turned on and that no fault is present. If a fault is present, the menu system will not be accessible.

Refer to [Figure 4-2](#) for the programming flow chart for the Millennium transmitter. The following steps outline the actions required to navigate through the menu system:

- Press and hold the **Setup** button or hold the magnet next to the triangle on the faceplate as shown in [Figure 3-1](#) until the message `Switch On` displays and the countdown (10 to 0) finishes.
- An option will scroll across the display followed by the prompt `YES?`.
- To set/view an option, momentarily press the **Setup** button or place the magnet to the Reed switch at the `YES?` prompt.
- If you do not wish to select that option wait five (5) seconds until the next option appears and then select `YES?`.
- A selection is acknowledged with a flashing `YES`.
- If no option is selected, the transmitter returns to the normal operational mode and the display will read `Clear`.

---

**Important**

When the menu system has been entered, the current output will change to 3 mA. Ensure that external systems are bypassed, as required, prior to entering the menu system.

---

## 4.3.1 Zero

If at any time the background particulate levels change, the transmitter may be zeroed to the new levels. Zeroing is recommended every 3 months.

---

**Important**

After initial power-up, allow the unit to warm up for 2-4 hours before zeroing.

---

If the sensor has been in operation for a period of time it is recommended that the window is cleaned as outlined in [Section 5.2](#).

Be sure the APM is energized up and is not indicating a fault; e.g. the display reads `Clear`, and the status LED is blinking green, and the current output is 4.0 mA.

Prior to beginning the zeroing procedure the air surrounding the APM should be clean and free of particulate or at the accepted background level for the specific application.

The following steps outline the procedure to perform a zero of the APM sensor.

**Procedure**

1. Press and hold the **Setup** button or the magnet to the Reed switch to enter the main menu; wait for the countdown, from 10 to 0, to end.
2. Release the **Setup** button or remove the magnet from the Reed switch.

The current output will move to 3.0 mA.

3. When `Set Zero` and then `YES?` is displayed press the **Setup** button or use the Reed switch to select this option.
4. A flashing `YES` will confirm your selection.

The APM has now been zeroed meaning that the existing level of air contamination is considered normal.

---


**Tip**

If your application has a constant level of particulate present that is required to be ignored by the APM you can set the zero level with the known particulate present as shown in [Figure 4-1](#).

---

To further fine tune the APM response for your requirements the sensitivity settings can be adjusted accordingly. Refer to [Section 4.3.2](#).

---

**Figure 4-1: Zero Level Setting**


### 4.3.2 Sensitivity settings

The APM can be set to detect low, medium or high sensitivity levels with high being the most sensitive. By default the sensitivity is set for high sensitivity from the factory. Follow the steps below to change the sensitivity.

1. Press and hold the **Setup** button or the magnet to the Reed switch to enter the main menu; wait for the countdown, from 10 to 0, to end.
2. Release the **Setup** button or remove the magnet from the Reed switch.

The current output will move to 3.0 mA.

3. When *Sensitivity Settings* and then *YES? Is* displayed press the **Setup** button or use the Reed switch to select this option.

A flashing *YES* will confirm your selection.

4. The following three options will display: *Low Sensitivity YES?* , *Medium Sensitivity YES?* and *High Sensitivity YES?*
5. When the required setting is displayed, press the **Setup** button or use the Reed switch to select.

The selection is acknowledged with flashing *YES*.

### 4.3.3 Review relay settings

This is a read-only mode to provide a summary of the relay settings. Changes to the relay settings cannot be made in this menu item.

#### Procedure

1. Press and hold the Setup button or the magnet to the Reed switch to enter the main menu; wait for the countdown, from 10 to 0, to end.
2. Release the Setup button or remove the magnet from the Reed switch.

The current output will move to 3.0 mA.

3. When *Review Relay Settings* and then *YES?* is displayed press the Setup button or use the Reed switch to select this option.

A flashing YES confirms the selection and the settings will be displayed.

### 4.3.4 Set relay options

This section outlines how to change the normal operation of the *Clean Window* and *Alarm* relays.

Follow the steps below to alter the relay functions or refer to [Figure 4-2](#).

---

#### Note

The *Fault Alarm* relay settings are fixed as normally *Energized* and *Non-Latching* and are not adjustable within the menu system.

---

#### Procedure

1. Press and hold the **Setup** button or the magnet to the Reed switch to enter the main menu; wait for the countdown, from 10 to 0, to end.
2. Release the Setup button or remove the magnet from the Reed switch.

The current output will move to 3.0 mA.

3. When *Set Relay Options* and then *YES?* is displayed, press the **Setup** button or use the Reed switch to select.

A flashing YES will confirm your selection. The message *Set Clean Window Alarm* and then *YES?* will be displayed.

4. Press the **Setup** button or use the Reed switch to select this option.

The flashing YES will confirm this selection. After the *Clean Window Alarm* option has been chosen the message *Coil Status* will be displayed followed by *Energized YES?*.

5. ii) To select that the relay be energized under normal conditions, press the Setup button or use the Reed switch to select this option.

- To select that the relay be de-energized under normal conditions wait five (5) seconds for the next selection. If energized has been selected, a flashing YES will confirm the selection.
6. To select that the relay be de-energized under normal conditions, press the **Setup** button or use the Reed switch to select this option.  
  
If the relay is setup as required, wait five (5) seconds for the next selection. If De-energized has been selected, a flashing YES will confirm the selection.  
  
The display will now show `Latch Status`, followed by `Latching YES?`.
  7. To select that the relay be latched in its alarm state, press the **Setup** button or use the Reed switch to select this option.  
  
To select that the relay be non-latching, wait five (5) seconds for the next selection. If latching has been selected, a flashing YES will confirm the selection.
  8. To select that the relay be non-latching, press the **Setup** button or use the Reed switch to select this option.  
  
If the relay is setup as required, wait five (5) seconds for the next selection. If non-latching has been selected, a flashing YES will confirm the selection.  
  
The message `Set Alarm` and then `YES?` will be displayed.
  9. Press the **Setup** button or use the Reed switch to select this option.  
  
A flashing YES will confirm this selection. After the Set Alarm option has been chosen, the message `Coil Status` will be displayed, followed by `Energized YES?`.
  10. To select that the relay be energized under normal conditions, press the **Setup** button or use the Reed switch to select this option.  
  
To select that the relay be de-energized under normal conditions, wait five (5) seconds for the next selection. If energized has been selected, a flashing YES will confirm the selection.
  11. To select that the relay be de-energized under normal conditions, press the **Setup** button or use the Reed switch to select this option.  
  
If the relay is setup as required, wait five (5) seconds for the next selection. If de-energized has been selected, a flashing YES will confirm the selection.  
  
The display will now show `Latch Status`, followed by `Latching YES?`.
  12. To select that the relay be latched in its alarm state, press the **Setup** button or use the Reed switch to select this option.  
  
To select that the relay be non-latching, wait five (5) seconds for the next selection. If latching has been selected, a flashing YES will confirm the selection.
  13. To select that the relay be non-latching, press the **Setup** button or use the Reed switch to select this option.

If the relay is setup as required, wait five (5) seconds for the next selection. If non-latching has been selected, a flashing `YES` will confirm the selection.



## 4.3.5 Select display language

This section outlines how to change the main display language to English, Spanish, or French. Follow the steps below to change the display language.

1. Press and hold the **Setup** button or the magnet to the Reed switch to enter the main menu; wait for the countdown, from 10 to 0, to end.
2. Release the **Setup** button or remove the magnet from the Reed switch.

The current output will move to 3.0 mA.

3. When `Select Display Language` and then `YES?` is displayed, press the **Setup** button or use the Reed switch to select. A flashing `YES` will confirm your selection.

The message `English` and then `YES?` will be displayed.

4. Press the **Setup** button or use the Reed switch to select this option. The flashing `YES` will confirm this selection. If English is not the desired language, wait five (5) seconds for the next selection.


The message `Espanol` and then `YES?` will be displayed.

5. Press the **Setup** button or use the Reed switch to select this option. The flashing `YES` will confirm this selection. If Spanish is not the desired language, wait five (5) seconds for the next selection.

The message `Francais` and then `YES?` will be displayed.

6. Press the **Setup** button or use the Reed switch to select this option. The flashing `YES` will confirm this selection. If French is not the desired language, wait five (5) seconds for the next selection.

Figure 4-2: Programming flowchart



# 5 Maintenance

## 5.1 Response check

It is recommended that the APM be checked and tested at least once every three months.

Spray Smoke Detector Tester (or equivalent product) in the direction of the sensor from a distance of two feet. Typically, a one to two second burst is adequate to initiate an alarm.

When the alarm activates, the display will read *Alarm*, the Status LED will flash red, and the current output will be 20.0 mA to indicate detection of particulate matter or canned contaminant.

After simulation, reset the alarm if latched as outlined in [Section 3.4](#) and zero the APM as per [Section 4.3.1](#) in clear air free of particulates or at the accepted particulate background level for the specific application.

---

### Note

The overuse of artificial particulate detector testers or spraying from too close a range may impair the operation of the APM due to the accumulation of an oily film on the internal window.

---

## 5.2 Cleaning

The APM Sensor should be routinely cleaned. The frequency of cleaning will depend on the application and environment where the APM is installed.

When the *Dirty Chamber* or *Clean Window Alarm* message is displayed, the lens / window and chamber will require cleaning. Follow the steps below when cleaning.

### Procedure

1. Turn off power to the transmitter.
2. Unscrew bolts at the end of circular plate and connecting rods.
3. Using the included window cleaning kit (HDW-0061), clean the inner sides of the sensor chamber and front side of the lens / window.
4. Ensure that there is no residue left on the lens or window.
5. Put the circular plate back into position, ensuring that the textured surface faces the APM window, and screw in the bolts at the end of the connecting rods.
6. Return power to the APM and check for normal operation.
7. Complete the Zero procedure to establish new settings.

If problems develop and persist, contact Net Safety Service department or refer to [Section 1.3](#) (Return of material).

## 5.3 Troubleshooting

The Millennium Transmitter and APM Sensor are not designed to be repaired in the field. If a problem should develop carefully check for faulty wiring. If it is determined that the problem is caused by an electronic defect, the device must be returned to the factory for repair (refer to [Section 1.2](#) and [Section 1.3](#) for instructions).

Regular checks should be done on the unit around every two to three months to ensure desired operation. Refer to [Section 5.1](#) for instructions.

## 5.4 Storage

The sensor and its electronic components/parts should be stored in locations free from dust and moisture. The storage temperature should be well within the limits of the certified temperatures of the equipment. See [Section 8.2.1](#) for storage temperatures.

## 5.5 Spare parts and accessories

**Table 5-1: Spare Parts and Accessories**

Description	Part Number
Universal duct mount assembly with 1 m inlet sampling tube	UDM-001
Universal duct mount assembly with 1.5 m inlet sampling tube	UDM-002
Universal Duct Mount Assembly	UDM-003
Magnet assembly	MAGNET-1
Replacement Millennium transmitter board	ML7-TX700
Mechanical relay board	ML7-RL305
Option board (mates with relay board)	ML7-OP100
Mechanical relay board c/w option board	ML7-ORL305
Window cleaning kit	HDW-0061
Terminal board for JB-MPD	JB-MPD-PCBA
Aluminum termination junction box	JB-MPD-A
316 stainless steel termination junction box	JB-MPD-S
Conduit reducer - 3/4" to M20 - aluminum	M20R
Conduit reducer - 3/4" to M20 - stainless steel	M20R-SS



## 6 Electrostatic sensitive device

Definition: Electrostatic discharge (ESD) is the transfer, between bodies, of an electrostatic charge caused by direct contact or induced by an electrostatic field.

The most common cause of ESD is physical contact. Touching an object can cause a discharge of electrostatic energy. If the charge is sufficient and occurs near electronic components, it can damage or destroy those components. In some cases, damage is instantaneous, and an immediate malfunction occurs. However, symptoms are not always immediate—performance may be marginal or seemingly normal for an indefinite period of time, followed by a sudden failure.

To eliminate potential ESD damage, review the following guidelines:

- Handle boards by the sides — taking care not to touch electronic components.
- Wear grounded wrist or foot straps, ESD shoes, or heel grounders to dissipate unwanted static energy.
- Prior to handling boards, dispel any charge in your body or equipment by touching a grounded metal surface.
- Ensure all components are transported and stored in ESD safe packaging.
- When returning boards, carefully package in the original carton and static protective wrapping.
- Ensure all personnel are educated and trained in ESD control procedures.
- Clean off the housing with a damp cloth only.

In general, exercise accepted and proven precautions normally observed when handling electrostatic sensitive devices.





## 7 Wire resistance table

<b>Distance Feet (Meters)</b>	<b>AWG #20 0.5 mm<sup>2</sup></b>	<b>AWG #18 0.8 mm<sup>2</sup></b>	<b>AWG #16 1.0 mm<sup>2</sup></b>	<b>AWG #14 2.0 mm<sup>2</sup></b>
100 (30.5)	1.02	0.64	0.40	0.25
200 (61)	2.03	1.28	0.80	0.51
300 (91.4)	3.05	1.92	1.20	0.76
400 (121.9)	4.06	2.55	1.61	1.01
500 (152.4)	5.08	3.20	2.01	1.26
600 (182.9)	6.09	3.83	2.41	1.52
700 (213.4)	7.11	4.47	2.81	1.77
800 (243.8)	8.12	5.11	3.21	2.02
900 (274.3)	9.14	5.75	3.61	2.27
1000 (304.8)	10.20	6.39	4.02	2.53
1250 (381)	12.70	7.99	5.03	3.16
1500 (457.2)	15.20	9.58	6.02	3.79
1750 (533.4)	17.80	11.20	7.03	4.42
2000 (609.6)	20.30	12.80	8.03	5.05
2250 (685.8)	22.80	14.40	9.03	5.68
2500 (762)	25.40	16.00	10.00	6.31
3000 (914.4)	30.50	19.20	12.00	7.58
3500 (1066.8)	35.50	22.40	14.10	8.84
4000 (1219.2)	40.60	25.50	16.10	10.00
4500 (1371.6)	45.70	28.70	18.10	11.40
5000 (1524)	50.10	32.00	20.10	12.60
5500 (1676.4)	55.80	35.10	22.10	13.91
6000 (1828.8)	61.00	38.30	24.10	15.20
6500 (1981.2)	66.00	41.50	26.10	16.40
7000 (2133.6)	71.10	44.70	28.10	17.70
7500 (2286)	76.10	47.90	30.10	19.00
8000 (2438.4)	81.20	51.10	33.10	20.20
9000 (2743.2)	91.40	57.50	36.10	22.70
10000 (3048)	102.00	63.90	40.20	25.30

Resistance shown is one way. This figure must be doubled when determining closed loop resistance.



## 8 Specifications

### 8.1 Electrical

#### 8.1.1 Operating voltage range

10.5 to 32Vdc

#### 8.1.2 Power consumption

3.24W max at 12 Vdc

3.6W max at 24 Vdc

#### 8.1.3 Current output

4-20 mA into a maximum loop impedance of 800 Ohms at 32 Vdc or 150 Ohms at 10.5 Vdc isolated or non-isolated loop supply

### 8.2 Environmental

#### 8.2.1 Storage temperature

Transmitter: -40 °F to +185 °F (-40 °C to +85 °C)

APM Sensor: -40 °F to +167 °F (-40 °C to +75 °C)

Junction Box: -40 °F to +185 °F (-40 °C to +85 °C)

#### 8.2.2 Operating temperature

Transmitter: -40 °F to +185 °F (-40 °C to +85 °C)

APM Sensor: -40 °F to +167 °F (-40 °C to +75 °C)

Junction Box: -40 °F to +185 °F (-40 °C to +85 °C)

#### 8.2.3 Relative humidity

0-100% relative humidity, non-condensing

## 8.2.4 Metallurgy

Aluminum (AL6061 - Sensor, A413 - Junction Box)

Stainless steel (SS316)

## 8.2.5 Ingress protection

Transmitter

- Type 4X
- IP66 IP67 (IECEX Stainless Steel)

Junction Box

- Type 4X
- IP67

APM Sensor

- Type 4X
- IP65

## 8.2.6 Weight

Transmitter

- Aluminum: 6.0 lbs, 2.6 kg
- Stainless steel: 7.0 lbs, 3.2 kg

APM Sensor

- Aluminum: 1.5lbs, 0.6kg
- Stainless steel: 4.0lbs, 1.8kg

Junction box

- Aluminum: 2.0lbs, 0.8kg
- Stainless steel: 3.5lbs, 1.6kg

## 8.3 Separation

Up to 2000 feet (610 meters) with 16 AWG (1.31 mm<sup>2</sup>) wire.

## 8.4 Warranty

Electronics: 3 years

Sensors: 2 years



## 9 Certifications

### 9.1 North American hazardous locations

#### 9.1.1 Transmitter



Class I, Division 1, Groups B, C, and D T5

Class I, Zone 1 Ex d IIB+H<sub>2</sub> T5 AL Version Only

-40 °C ≤ Ta ≤ +75 °C

Type 4X

#### 9.1.2 APM Sensor



Class I Division 1 Groups B, C, and D T5

Class I Zone 1 AEx db IIB+H<sub>2</sub> T5 Gb

Ex db IIB+H<sub>2</sub> T5 Gb

IP65, Type 4X

-40 °C ≤ Ta ≤ +75 °C

### 9.1.3 Junction box (Model JB-MPD)



Class I, Division 1, Groups B, C, and D Class I Zone 1, AEx d/Ex d IIB+H<sub>2</sub> T5

-50 °C ≤ Ta ≤ +85 °C

Type 4X, IP67

## 9.2 ATEX (-X model)

### 9.2.1 Transmitter

CE 0575 II 2 G Ex d IIB+H<sub>2</sub> T5, IP65

-40 °C ≤ Ta ≤ +85 °C

Presafe 16 ATEX 8594X

### 9.2.2 APM Sensor



CE 0575 II 2 G Ex d IIB+H<sub>2</sub> T5, IP65

-40 °C < Ta < +75 °C

SIRA 17ATEX1242X


Special conditions for safe use

1. The permanently connected cable needs appropriate protection of the free end of the cable.
2. The parts of the bushing outside the flameproof enclosure shall be protected in accordance with one of the types of protection listed in EN60079-0.
3. The electrical earth bonding of the equipment shall be ensured during installation.



### 9.2.3 Junction box (Model JB-MPD)



CE 0575  II 2 G Ex d IIB+H<sub>2</sub> T5

-55 °C ≤ Ta ≤ +85 °C IP67

FM07ATEX0044

## 9.3 IECEx (-X model)

### 9.3.1 Transmitter (aluminum)

Ex d IIB+H<sub>2</sub> T5 Gb

-40 °C ≤ Ta ≤ +85 °C

Certificate Number: IECEx DNV 12.0014

IEC 60079-0: 2007-10/IEC 60079-1:2007-04

### 9.3.2 Transmitter (stainless steel)

Ex d IIB+H<sub>2</sub> T5 Gb

-55 °C ≤ Ta ≤ +85 °C

Certificate Number: IECEx FMG 13.0035X

IEC 60079-0:2011/IEC 60079-1:2007/IEC 60529:2001

Consult the manufacturer if dimensional information on the flameproof joints is necessary.

### 9.3.3 APM Sensor

Ex d IIB+H<sub>2</sub> T5 Gb IP65

-40 °C ≤ Ta ≤ +75 °C

Certificate Number: IECEx SIR 17.0061X

### 9.3.4 Junction Box (Model JB-MPD)

Ex d IIB+H<sub>2</sub> T5 Gb

Certificate Number: IECEx FMG 14.0009X

Consult the manufacturer if dimensional information on the flameproof joints is necessary.

Follow the manufacturer's instructions to reduce the potential of an electrostatic charging hazard.

# 10 Ordering information

Model	Description
MLP	Millennium Transmitter
Output	Description
-AR	4-20mA Analog and Particulate & Fault Alarm Relays
Sensor	Description
-APM	Air Particle Monitor
Optics	Description
-OP	Optical Protection
Separation	Description
-SEP	Sensor separation
Housing	Description
	Aluminum
-SS	Stainless steel
Approvals	Description
	CSA
-X	ATEX/IECEX

## Note

Emerson  
 Rosemount  
 6021 Innovation Blvd.  
 Shakopee, MN 55379

Toll Free + 866 347 3427

F +1 952 949 7001

[www.Emerson.com/FlameGasDetection](http://www.Emerson.com/FlameGasDetection)









[www.Emerson.com/FlameGasDetection](http://www.Emerson.com/FlameGasDetection)

Rosemount

6021 Innovation Blvd.

Shakopee, MN 55379

Toll Free + 866 347 3427

F +1 952 949 7001

[safety.csc@emerson.com](mailto:safety.csc@emerson.com)

[www.Emerson.com/FlameGasDetection](http://www.Emerson.com/FlameGasDetection)

#### EUROPE

Emerson Automation Solutions

Neuhofstrasse 19a P.O. Box 1046

CH-6340 Baar

Switzerland

T + 41 (0) 41 768 6111

F + 41 (0) 41 768 6300

[safety.csc@emerson.com](mailto:safety.csc@emerson.com)

[www.Emerson.com/FlameGasDetection](http://www.Emerson.com/FlameGasDetection)

#### MIDDLE EAST AND AFRICA

Emerson Automation Solutions

Emerson FZE

Jebel Ali Free Zone

Dubai, United Arab Emirates, P.O. Box 17033

T +971 4 811 8100

F +971 4 886 5465

[safety.csc@emerson.com](mailto:safety.csc@emerson.com)

[www.Emerson.com/FlameGasDetection](http://www.Emerson.com/FlameGasDetection)

#### ASIA-PACIFIC

Emerson Automation Solutions

Asia Pacific Private Limited

1 Pandan Crescent

Singapore 128461

Singapore


T +65 777 8211

F +65 777 0947


[safety.csc@emerson.com](mailto:safety.csc@emerson.com)


[www.Emerson.com/FlameGasDetection](http://www.Emerson.com/FlameGasDetection)

 [Linkedin.com/company/Emerson-Automation-Solutions](https://www.linkedin.com/company/Emerson-Automation-Solutions)

 [twitter.com/rosemount\\_news](https://twitter.com/rosemount_news)

 [Facebook.com/Rosemount](https://www.facebook.com/Rosemount)

 [youtube.com/RosemountMeasurement](https://www.youtube.com/RosemountMeasurement)

 [google.com/+RosemountMeasurement](https://plus.google.com/+RosemountMeasurement)

 [AnalyticExpert.com](http://AnalyticExpert.com)

The Emerson logo is a trademark and service mark of Emerson Electric Co. Rosemount and Rosemount logotype are trademarks of Emerson. All other marks are property of their respective owners.